

APPENDIX A: SPREADSHEET CALCULATION – EXAMPLE

This example is the standard case where increased traffic loading is expected on a set of quarry roads, and the net present value resulting from the changed activity is to be quantified, using the Austroads Simplified Approach.

